



OWNER'S MANUAL

Models

14" Metal Oscillating Pedestal Fan

FP-1430DTO-MBL

FP-1430DTO-MBR

FP-1430DTO-MCH

16" Metal Oscillating Pedestal Fan

FP-1630DTO-MBL

FP-1630DTO-MBR

FP-1630DTO-MCH

18" Metal Oscillating Pedestal Fan

FP-1830DTO-MBL

FP-1830DTO-MBR


FP-1830DTO-MCH



To obtain the best performance of this fan, please read these instructions carefully before using. We also recommend keeping the instructions for future reference.

OVERVIEW OF FUNCTIONS

1. Fan grill
2. Fan blades
3. Motor housing
4. Oscillation button
5. Speed dial
6. Fan/stand attachment bolt
7. Angle-adjustment knob
8. Power cord and plug
9. Height lock
10. Standing pipe
11. Base



Model:14" Pedestal
 FP-1430DTO-MBL
 FP-1430DTO-MBR
 FP-1430DTO-MCH

Model:16" Pedestal
 FP-1630DTO-MBL
 FP-1630DTO-MBR
 FP-1630DTO-MCH

Model:18" Pedestal
 FP-1830DTO-MBL
 FP-1830DTO-MBR
 FP-1830DTO-MCH

TECHNICAL DETAILS

Rated voltage: 120V~60Hz
 Rated power: 50W


IMPORTANT SAFETY MEASURES

Please ensure that the voltage of the fan corresponds to the supply voltage.


- Use the fan only for the purpose(s) defined in the user guide.
- Never insert your fingers, pencils or other objects through the fan cage during operation.
- Switch the fan off before moving or cleaning.
- The fan should be set up on a stable and level surface to avoid being knocked over.
- Do not expose the fan to excessive heat or humidity, to prevent damage to the electrical components.
- Do not immerse in any form of liquid.
- It is not recommended to expose babies and the elderly to a continuous stream of cold air.
- The fan should be kept out of reach of children.
- Ensure that the powercord does not get caught beneath the device, in drawers, behind shelves etc.
- Do not run the powercord under carpets, rugs, etc.
- Ensure the powercord is kept away from busy areas to avoid anyone tripping over it.
- Do not use if the device or powercord becomes damaged. Take it to an electrician for repair.
- For indoors use only.

SETTING UP THE FAN


- Remove the base nut from the standing pipe. And then insert the standing pipe into the hole of base, put the heavy base under the base. Fit the base nut back to the standing pipe and screw it on firmly. See the picture of "OVERVIEW OF FUNCTIONS"
- Remove the 4pcs screws from the motor.
- Fit the rear fan grill onto the motor. Make sure that the 4 holes on the motor match the 4 holes on the rear fan grill. Fit the 4pcs screws and tighten the screws.
- Install the blade in correct orientation for proper air flow on the motor shaft and carefully tighten the screw.
- Fit the front fan grill onto the rear cage and attach them together using the metal clips.



Step 1: Remove the 4pcs screws




Step 2: Fit the rear fan grill and install the screws



Step 3: Insert blade on the shaft and tighten



Step 4: Put the front grill on the rear grill



Step 5: Press the clips and install the safety screw

USE

The fan has 3 speed settings:

- 0- Fan is off
- 1- Lowest speed
- 2- Medium speed
- 3- High speed

The fan can operate in oscillating or stationary mode. Press the oscillation button to activate the oscillating mode.

CLEANING

- Always switch the fan off and unplug it before cleaning.
- Clean the parts using a damp cloth and a mild detergent, and ensure that all detergent residues are removed.
- Never use abrasive cleaning agents or solvents.
- Do not immerse in any form of liquid.

Warning: in order to reduce the risk of fire or electric shock, never use the appliance together with an electronic timer.

SAFETY PRECAUTIONS

- 1) This appliance is not intended for use by children unless they are properly supervised.
- 2) Children should be supervised to ensure that they do not play with the appliance.
- 3) Have any repairs carried out solely by a qualified electrician. Never try to repair the appliance yourself.

LIMITED EXPRESS WARRANTY

Congratulations on purchasing your new HVAC equipment. It's been designed for long life and reliable service, and is backed by one of the strongest warranties in the industry. Your item automatically qualifies for the warranty coverage listed below, providing you keep your proof of purchase (receipt) for the equipment and meet the warranty conditions.

LIMITED ONE (1) YEAR EXPRESS WARRANTY

Comfort-Aire warrants item to be free from defects in workmanship and materials for normal use and maintenance for one (1) year from the date of purchase by the original consumer. This Express Limited Warranty applies only when operated per Comfort-Aire installation and operating instructions for normal use.

EXCEPTIONS

The Limited Express Warranty does not cover normal maintenance Comfort-Aire recommends that regular inspection/maintenance be performed at least once a season.

CONDITIONS FOR WARRANTY COVERAGE

Item must be operated according to Comfort-Aire operating instructions included with the unit and cannot have been subjected to accident, alteration, improper repair, neglect or misuse, or an act of God (such as a flood)

- Serial numbers and/or rating plate have not been altered or removed
- Performance cannot be impaired by use of any product not authorized by Comfort-Aire, or by any adjustments or adaptations to components
- Damage has not been a result of inadequate wiring or voltage conditions, use during brown-out conditions, or circuit interruptions

DURATION OF WARRANTY & REGISTRATION

The warranty begins on the date of purchase by the original consumer. The consumer must retain a receipt as proof of warranty period. Without this proof, the express warranty begins on the date of shipment from the factory.

REMEDY PROVIDED BY THE LIMITED EXPRESS WARRANTY

The sole remedy under the Limited Warranty is replacement of the defective unit. Labor to diagnose and replace the defective unit is not covered by this Limited Express Warranty. If for any reason the replacement product is no longer available during the warranty period, Comfort-Aire shall have the right to allow a credit in the amount of the current suggested retail price of the product instead of providing replacement.

LIMITATION OF LIABILITY

1. There are no other express or implied warranties. Comfort-Aire makes no warranty of merchantability. We do not warrant that the unit is suitable for any particular purpose or can be used in buildings or rooms of any particular size or condition except as specifically provided in this document. There are no other warranties, express or implied, which extend beyond the description in this document.
2. All warranties implied by law are limited in duration to the one-term of the warranty. We will not be liable for any consequential or incidental damages caused by any defect in this item.
3. This warranty gives you specific legal rights and you may also have other rights which vary from state to state. Some states do not allow limitation on how long an implied warranty lasts or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.
4. No warranties are made for items sold outside the continental United States and Canada. Your distributor or final seller may provide a warranty on items sold outside these areas.
5. Comfort-Aire will not be liable for damages if our performance regarding warranty resolution is delayed by events beyond our control including accident, alteration, abuse, war, government restrictions, strikes, fire, flood, or other acts of God.

HOW TO SUBMIT A WARRANTY CLAIM

If you have a warranty claim, notify you installer or dealer promptly.

KEEP THIS INFORMATION AS A RECORD OF YOUR PURCHASE

PRODUCT IDENTIFICATION

Model Number _____

Serial Number _____

Date of Purchase _____

Remember to retain your bill of sale as proof of warranty period.

Fans_3-2020

Due to ongoing product improvements, specifications and dimensions are subject to change and correction without notice or incurring obligations. Determining the application and suitability for use of any product is the responsibility of the installer. Additionally, the installer is responsible for verifying dimensional data on the actual product prior to beginning any installation preparations.

Incentive and rebate programs have precise requirements as to product performance and certification. All products meet applicable regulations in effect on date of manufacture; however, certifications are not necessarily granted for the life of a product.

Therefore, it is the responsibility of the applicant to determine whether a specific model qualifies for these incentive/rebate programs.

Comfort-Aire®

1900 Wellworth Ave., Jackson, MI 49203 • Ph. 517-787-2100 • www.marsdelivers.com

